Technical Information

TEGOSOFT® OS

Medium viscous cosmetic oil with medium spreadability

Intended use

Liquid lipophilic emollient

Benefits at a glance

- Emollient ester with low occlusivity
- Oxidation stable
- Universal use

INCI (PCPC Name)

Ethylhexyl Stearate

Chemical and physical properties

(not part of specifications)

Form	liquid	
Color	colorless to slightly yellow	

Further product information (not part of specifications)

Density (g/cm³)	approx. 0.85
Viscosity at 25 °C according to Höppler (mPas)	approx. 12
Surface tension at 25 °C according to ring method (mN/m)	approx. 30
Spreadability	medium spreadability
Polarity	low polarity

Pour point following	
DIN ISO 3016 (°C)	

approx. 8

Properties

- Medium viscous cosmetic ester with medium spreading properties
- Miscible with other cosmetic oils and fats
- Oxidation stable

Application

TEGOSOFT® OS is suitable for

- all types of creams and lotions
- body oils
- bath additives

Packaging

720 kg pallet (4 x 180 kg)

Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transport and for dangerous substances
- protective measures for storage and handling
- measures in case of accidents and fires
- toxicity and ecological effects

is given in our material safety data sheets.

Guideline formulations

W/O Lotion		
F 13/97		
Phase A		
ABIL [®] EM 90 (Cetyl PEG/PPG-10/1	2.00%	
Dimethicone)		
TEGOSOFT [®] OS	7.00%	
TEGOSOFT® liquid (Cetearyl Ethylhexanoate)	7.00%	
Isohexadecane	7.00%	
Microcristalline Wax (Paracera W 80, Paramelt B.V.)	0.50%	
Hydrogenated Castor Oil	0.50%	
Phase B		
Sodium Chloride	0.50%	
LACTIL® (Sodium Lactate; Sodium PCA; Glycine; Fructose; Urea; Niacinamide; Inositol; Sodium Benzoate; Lactic Acid)	2.00%	
Water	68.50%	
Phase C		
Alcohol	5.00%	
Phase Z		
Preservative, Perfume q.s.		
 Preparation: Heat phase A to approx. 80 °C. Add phase B (80 °C or room tempera while stirring. Homogenize for a short time. 	ture) slowly	
1 Cool with gentle stirring and add phase C		

- 4. Cool with gentle stirring and add phase C below 40 °C.
- 5.Homogenize again below 30 °C.

O/W Urea Softcream BR 3/11-3	
Phase A	
TEGO° Care PSC 3 (Polyglyceryl–3 Dicitrate/Stearate)	3.00%
TEGIN® M Pellets (Glyceryl Stearate)	1.50%
TEGO° Alkanol 1618 (Cetearyl Alcohol)	1.00%
TEGOSOFT® CT (Caprylic/Capric Triglyceride)	6.00%
TEGOSOFT [®] OS	3.00%
TEGOSOFT [®] DC (Decyl Cocoate)	2.50%
Phase B	
Water	59.99%
Glycerin 3.00	
Phase C	
Water	10.00%
Urea	10.00%
Triacetin (Glyceryl Triacetate) 0.01%	
Phase Z	
Preservative, Perfume	q.s.
 Preparation: 1. Heat phase A and B separately to ap 70 - 75 °C. 2. Add phase A to phase B with stirring 	
 Homogenize. Cool with gontle stirring 	

4. Cool with gentle stirring.

5. Add phase C below 40 °C. ¹⁾Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Night Recovery Cream F 34/08-38	
Phase A	
ABIL® Care XL 80 (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	1.00%
TEGO® Care 450 (Polyglyceryl–3 Methylglucose Distearate)	2.00%
TEGIN® M Pellets (Glyceryl Stearate)	3.50%
TEGO [®] Alkanol 18 (Stearyl Alcohol)	1.50%
TEGOSOFT [®] OS	8.50%
TEGOSOFT® DEC (Diethylhexyl Carbonate)	8.50%
Phase B	
Glycerin	3.00%
Water	72.00%
Phase Z	-
Preservative, Perume	q.s.
 Preparation: Heat phase A and B separately to ap 70 - 75 °C. Add phase A to phase B with stirring Homogenize. Cool with gentle stirring. 	
DImportant: If phase A has to be charg vessel first, phase B must be added wit stirring.	

Phase A		
TEGOSOFT® LSE 65 K SOFT (Sucrose Cocoate)	1.00%	
Mineral Oil (30 mPas)	7.00%	
TEGOSOFT [®] OS (Ethylhexyl Stearate)	6.00%	
TEGIN® M Pellets (Glyceryl Stearate)	5.00%	
TEGO® Alkanol 1618 (Cetearyl Alcohol)	5.00%	
Phase B		
Water	75.00%	
Phase C		
TEGO [®] Carbomer 134 (Carbomer)	0.20%	
TEGOSOFT [®] OS	0.80%	
Phase D		
Sodium Hydroxide (10% in water)	q.s.	
Phase Z		
Preservative, Perfume	q.s.	
Preparation:		
1. Heat phase A and B separately to approx. 70 - 75 °C.		
2. Add phase A to phase B with stirring ^{1).}		
3. Homogenize.		
4. Add phase C at approx. 60 °C.		
5. Homogenize for a short time.		
6. Add phase D at 40 °C and stir well.		

F 07/13

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments.

stirring.

The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used. (Status: April, 2008)

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100 45127 Essen, Germany P.O.BOX 45116 Essen PHONE + 49 201 173-2854 FAX +49 173-1828

personal-care@evonik.com www.evonik.com/personal-care





Product specification

Material	TEGOSOFT OS	
Spec.Code	K00 STANDARD	

Evonik Nutrition & Care GmbH

Business Line Personal Care Goldschmidtstrasse 100 45128 Essen Phone: +49 (201) 173-2524 Fax: +49 (201) 173-1828 http://www.evonik.com/personal-care personal-care@evonik.com

Inspection Characteristics	Method	Limits	Units	Z
Refractive index / 20°C	GM_0120_01	1.4460-1.4490		Х
Density / 20°C	GM_0110_01	0.8540-0.8600	g/ml	х
Hydroxyl value	GM_0020_01	<=3.0	mg KOH/g	х
lodine value	GM_0050_01	<=1.00	g l/100g	х
Acid Value	GM_0010_01	<=1.00	mg KOH/g	Х
Saponification Value	GM_0030_04	142.0-156.0	mg KOH/g	Х

Report on inspection certificate: X = specific/actual value, C = unspecific value/conformity, T = not reported

This document is computer printed and therefore valid without signature.

All warranty claims in respect of the conformity of our product are subject to our General Terms and Conditions of Sale and

Delivery. The data listed above reflects the criteria for our internal quality tests. We do not hereby make any express or implied warranty, whether for specific properties or for fitness for any particular application or purpose. All values are valid for the product when despatched from the works.

The Standard Test Methods can be obtained from specialized publishers. Evonik's test methods are available on request.

Material: TEGOSOFT OS		Spec-Code: K00 STANDARD	Page 1 from 1
Print date: 06.07.2015	Valid from: 01.09.2007	Version: 5	



Edition 16 02 July 2015 Mat. Number G202240

TEGOSOFT[®] OS

Product data record

1. General information

Manufacturer/Supplier

 Evonik Nutrition & Care GmbH
 Business Line Personal Care
 Goldschmidtstrasse 100
 D-45127 Essen / Germany
 Phone: +49 (201) 173-2524
 Fax: +49 (201) 173-1828
 personal-care@evonik.com
 http://www.evonik.com/personal-care

1.2 Product Description

1.2.1 Raw material category Liquid Lipophilic Emollient

1.2.2 Ingredients according to INCI

Ethylhexyl Stearate

1.2.3 Composition

Components	Source	Ratio
Ethylhexyl Stearate	vegetable / synthetic	100 %

This composition information serves for information of our customers only. It is neither relevant for the composition listing according to Regulation (EC) No 1223/2009, nor does it reflect the chemical composition according to the different chemical regulations in the world which is disclosed in the table "information on ingredients/hazardous components" in the relevant parts of the respective (Material) Safety Data Sheets.

1.2.4 Solvents, preservatives and other additives

	CAS No.	EINECS / EC No.	content	Function
no additives				

No components which are listed in Annex II of the Regulation (EC) No 1223/2009 and its modifications and updates are added to and are not to be expected in the above mentioned product due to the raw materials used and the production process.

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could be used.



2. Information on production process

General description of production process: Esterification product

The product is not irradiated.

TEGOSOFT® OS is produced in the strictest absence of any animal derived material of any type.

Origin of vegetable starting material: palm oil

GMO-Status:

The item does not contain ingredients that might have been derived from GM sources. However max 0.9 % cross-contamination is possible. Any protein or DNA is not present. Consequently the product will be PCR negative when tested.

		method
Residual solvents	not applicable	
Free amines	not applicable	Chromatography
Nitrosamines	not applicable	
Monochloroacetic acid	not applicable	Chromatography
Dichloroacetic acid	not applicable	Chromatography
1,4-Dioxane	not applicable	
Pesticides	meets the valid regulatory requirements for limits on agricultural pesticides	
Total heavy metals	max. 20 ppm	AAS-ICP
As, Cd, Co, Cr, Hg, Ni, Pb, Sb	Each < 1 ppm	AAS-ICP
Latex	not to be expected in the product due to the raw materials used and the production process	
VOC	< 3 % according to SR (Swiss Right) 814.018	

2.1 By products

2.2 CMR (Carcinogenic, Mutagenic or Reprotoxic)

The use in cosmetic products of substances classified as CMR substances, of category 1A or 1B or 2 under Part 3 of Annex VI to Regulation (EC) No 1272/2008 shall be prohibited.

Further Information: http://eur-lex.europa.eu/LexUriServ/LexUriServ.do?uri=OJ:L:2009:342:0059:0209:en:PDF

Some of the CMR substances mentioned below and listed in Annex VI to Regulation (EC) No 1272/2008 are used as starting materials or solvents for the production of our cosmetic raw materials and may require reporting under California Proposition 65 or the Safe Cosmetics Act, SB 484.

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could be used.



The presence of these prohibited substances has to be seen as non-intended. It is stemming from impurities of the starting materials or the manufacturing process which is technically unavoidable in good manufacturing practice.

CMR substance	Starting material	max. concentration	method
Ethylene Oxide	no		
Propylene Oxide	no		
Octamethylcyclotetrasiloxane (D4)	no		
2-Ethylhexanoic Acid	no		
n-Hexane	no		
Methyl Chloride	no		
Dimethyl Sulphate	no		

2.3 "Allergens" according to the Regulation (EC) No 1223/2009

The presence of substances, the mentioning of which is required under the column 'Other' in Annex III, shall be indicated in the list of ingredients in addition to the terms parfum or aroma.

The cosmetic raw materials and the cosmetic actives supplied by Evonik Personal Care are manufactured without the use of perfumes and fragrances. An analytical proof for the absence in traces of the substances to be mentioned in addition to the terms parfum or aroma is not performed in cosmetic raw materials, which are chemically produced.

None of these substances have been intentionally added to our cosmetic raw materials or are formed during the manufacturing process according to our knowledge of the chemistry.

2.4 Food Ingredients listed in Annex IIIa of Commission Directive 2007/68/EC.

None of these substances have been intentionally added to our cosmetic raw materials or are formed during the manufacturing process according to our knowledge of the chemistry.

3. Microbiological status

Total Viable Countmax. 100 cfu/gPathogens*absent/g

*Pathogens are: Enterobacteria, Pseudomonas, Enterococci, Candida albicans, Staphylococci

4. Shelf life / storage conditions

24 months after production (unopened original packaging)



5. Regulatory Status

5.1 Customs tariff number 29157050

Regulatory status (chemical regulations)

Europe

5.2

Components	REACH status	CAS No.	EINECS / EC No.
Ethylhexyl Stearate	Reg. No. 01–2119970178–29		244-754-0

Other countries

Country		yes / no	Remark
Australia	AICS:	yes	
China	IECSC:	yes	
Canada	DSL: NDSL:	yes	
Taiwan	TCSI:	yes	

In the following countries the relevant authorities currently do not require pre-market approval for cosmetic raw materials:

Brazil, Japan, South Korea, Philippines, USA

5.2.1 Regulatory status (cosmetic regulation)

Country		yes / no	Remark
China	CFDA:	yes	
Japan	JSQI:	yes	JSQI No. 540049, but specifications not controlled

6. Toxicology and Ecotoxicology

Refer to summary of ecotoxicological and toxicological data